
# KEYPAD WALKTHROUGH GUIDE




FLOWPOINT

WATER EXCHANGE


## Single Hose Display





1. Using the Keypad, type in the Access code and then ENTER.





2. Enter in the associated PIN # and hit ENTER.




Invalid Access Code & PIN combination.




3. Access combo correct, enter in the desired volume and hit ENTER.




4. Hose Connected?, Yes Hit START to begin.





5. Users have the option to either PAUSE (120s max) or STOP a fill.





6. Fill Complete displays the Volume Dispensed and returns to the ready display.


## Single Hose - Pre-Pay Display





1. Using the Keypad, type in the Access code and then ENTER.




2. Enter in the associated PIN # and hit ENTER.




3. Users Pre-Paid Account Balance shown in US Gallons.




4. Enter in the desired volume and hit ENTER.




5. Hose Connected?, Yes Hit START to begin.




6. Users have the option to either PAUSE (120s max) or STOP a fill.




7. Fill Complete displays the Volume Dispensed and returns to the ready display.


FLOWPOINT

WATER EXCHANGE


## Multi-hose Display with Printer





1. Using the Keypad, select the desired Hose and hit ENTER.




2. Enter the Access Code and hit ENTER.




3. Enter in the associated PIN # and hit ENTER.





4. Enter in the desired volume and hit ENTER.




5. Hose Connected?, Yes Hit START to begin.





6. User can pre-request a RECEIPT, PAUSE (120s – max) or STOP a fill.





7. Fill Complete, user has a second opportunity to request a RECEIPT.

## Credit Card Unit Display with Printer




1. To pay by Credit Card, first hit the START key.




2. Enter in the desired volume and hit ENTER.





3. The Total $ Amount will be displayed prompting the user to Swipe or Tap a card for payment.




ePort Credit & Debit Card Reader




5. User can pre-request a RECEIPT, PAUSE (120s max) or STOP a fill.




6. Fill Complete, the card charges are displayed and a RECEIPT option appears.

FLOWPOINT

WATER +


FLOWPOINT

WATER EXCHANGE


## Additional Custom Display Options




Coin Acceptor & Credit Card Unit Display




Coin Acceptor Display




Bill & Coin Acceptor Display